

Using the TPS53219EVM-690 Wide-Input Voltage, Eco-mode™, Single, Synchronous, Step-Down Controller

The TPS53219EVM-690 evaluation module allows users to evaluate the Texas Instruments TPS53219, a small-sized, single, buck controller with adaptive on-time D-CAP™ mode control. Included in this document are operating and testing descriptions as well as the EVM schematic, bill of materials, and board layout.

Contents

1	Introduction	3
2	Description	3
	2.1 Typical Applications	3
	2.2 Features	3
3	Electrical Performance Specifications	3
4	Schematic	4
5	Test Setup	5
	5.1 Test Equipment	5
	5.2 Recommended Test Setup	6
6	Configurations	6
	6.1 Switching Frequency Selection	6
	6.2 Soft-Start Selection	7
	6.3 Mode Selection	7
	6.4 Enable Selection	7
7	Test Procedure	7
	7.1 Line/Load Regulation and Efficiency Measurement Procedure	7
	7.2 Control Loop Gain and Phase Measurement Procedure	8
	7.3 List of Test Points	8
	7.4 Equipment Shutdown	8
8	Performance Data and Typical Characteristic Curves	9
	8.1 Efficiency	9
	8.2 Load Regulation	9
	8.3 Output Transient	10
	8.4 Output Ripple	11
	8.5 Switching Node	11
	8.6 Enable Turnon/Turnoff	12
	8.7 Output 1.1-V Prebias Turnon	13
	8.8 Bode Plot	13
	8.9 Thermal Image	14
9	EVM Assembly Drawing and PCB Layout	15
10	Bill of Materials	19

List of Figures

1	TPS53219EVM-690 Schematic	4
2	Tip and Barrel Measurement for Vout Ripple	5
3	TPS53219EVM-690 Recommended Test Set Up	6
4	Efficiency	9

Eco-mode, D-CAP are trademarks of Texas Instruments.

5	Load Regulation	9
6	Output Load Transient	10
7	Output Load Transient	10
8	Output Ripple	11
9	Switching Node	11
10	Enable Turnon	12
11	Enable Turnoff	12
12	Output 1.1-V Prebias Turnon	13
13	Bode Plot at 12 Vin, 1.1 V/25 A	13
14	Top Board at 12 Vin, 1.1 V/25 A	14
15	Bottom Board at 12 Vin, 1.1 V/25 A	14
16	TPS53219EVM-690 Top Layer Assembly Drawing, Top View	15
17	TPS53219EVM-690 Bottom Assembly Drawing, Bottom View	15
18	TPS53219EVM-690 Top Copper, Top View	16
19	TPS53219EVM-690 Layer-2 Copper, Top View	16
20	TPS53219EVM-690 Layer-3 Copper, Top View	17
21	TPS53219EVM-690 Layer-4 Copper, Top View	17
22	TPS53219EVM-690 Layer-5 Copper, Top View	18
23	TPS53219EVM-690 Bottom Layer Copper, Top View	18

List of Tables

1	TPS53219EVM-690 Electrical Performance Specifications	3
2	Switching Frequency Selection	7
3	Soft-Start Selection	7
4	MODE Selection	7
5	Enable Selection	7
6	Functions of Each Test Points	8
7	The EVM Bill of Materials According to Schematic Shown in	19

1 Introduction

The TPS53219EVM-690 evaluation module (EVM) uses the TPS53219. The TPS53219 is a small-size, single buck controller with adaptive on-time D-CAP™ mode control. It provides a fixed 1.1-V output at up to 25 A from a 12-V input bus. TPS53219EVM-690 also uses the 5-mm x 6-mm TI power block MOSFET (CSD86350Q5D) for high power density and superior thermal performance.

2 Description

The TPS53219EVM-690 is designed to use a regulated 12-V bus to produce a regulated 1.1-V output at up to 25 A of load current. The TPS53219EVM-690 is designed to demonstrate the TPS53219 in a typical low-voltage application while providing test points to evaluate the performance of the TPS53219.

2.1 Typical Applications

- Point of load systems
- Storage computer
- Server computer
- Multifunction printer
- Embedded computing

2.2 Features

The TPS53219EVM-690 features:

- 25-Adc, steady-state output current
- Support prebias output voltage start-up
- High efficiency and high power density by using TI power block MOSFET
- J1 for selectable switching frequency setting
- J2 for selectable internal voltage servo soft-start
- J3 for enable function
- J6 for auto-skip and forced CCM selection
- Convenient test points for probing critical waveforms

3 Electrical Performance Specifications

Table 1. TPS53219EVM-690 Electrical Performance Specifications

PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNITS
INPUT CHARACTERISTICS					
Voltage range	VIN	8	12	14	V
Maximum input current	VIN = 8 V, IO = 25 A		4		A
No load input current	Vin = 14 V, IO = 0 A with auto-skip mode		1		mA
OUTPUT CHARACTERISTICS					
Output voltage VOUT			1.1		V
Output voltage regulation	Line regulation(Vin = 8 V-14 V)		0.5%		
	Load regulation(Vin = 12 V, IO = 0 A-25 A)		0.5%		
Output voltage ripple	Vin = 12 V, IO = 25 A		25		mVpp
Output load current		0		25	A
Output over current			35		A
SYSTEMS CHARACTERISTICS					
Switching frequency			300		kHz
Peak efficiency	Vin = 12 V, 1.1 V/10 A		90.90%		
Full-load efficiency	Vin = 12 V, 1.1 V/25 A		88.59%		
Operating temperature			25		°C

Note: Jumpers set to default locations, See Section 6 of this user's guide

4 Schematic




Figure 1. TPS53219EVM-690 Schematic

5 Test Setup

5.1 Test Equipment

Voltage Source: The input voltage source V_{in} must be a 0-V to 14-V variable dc source capable of supplying 10 Adc. Connect V_{in} to J4 as shown in Figure 3.

Multimeters:

V1: V_{in} at TP7 (V_{in}) and TP8 (GND).

V2: V_{out} at TP14 (V_{out}) and TP15 (GND).

A1: V_{in} input current

Output Load: The output load must be an electronic constant resistance mode load capable of 0 Adc to 30 Adc at 1.1 V.

Oscilloscope: A digital or analog oscilloscope can be used to measure the output ripple. The oscilloscope must be set for 1-M Ω impedance, 20-MHz bandwidth, ac coupling, 2- μ s/division horizontal resolution, 50-mV/division vertical resolution. Test points TP14 and TP15 can be used to measure the output ripple voltage by placing the oscilloscope probe tip through TP14 and holding the ground barrel on TP15 as shown in Figure 2. Using a leaded ground connection may induce additional noise due to the large ground loop.




Figure 2. Tip and Barrel Measurement for V_{out} Ripple

Fan: Some of this EVM's components may approach temperatures of 60°C during operation. A small fan capable of 200-400 LFM is recommended to reduce component temperatures while the EVM is operating. The EVM must not be probed if the fan is not running.

Recommended Wire Gauge:

1. V_{IN} to J4 (12-V input):
The recommended wire size is 1 x AWG 14 per input connection, with the total length of wire less than 4 feet (2-foot input, 2-foot return).
2. J5 to LOAD:
The minimum recommended wire size is 2 x AWG 14, with the total length of wire less than 4 feet (2-foot output, 2-foot return)

5.2 Recommended Test Setup




Figure 3. TPS53219EVM-690 Recommended Test Set Up

Figure 3 is the recommended test setup to evaluate the TPS53219EVM-690. Working at an ESD workstation, make sure that any wrist straps, bootstraps or mats are connected referencing the user to earth ground before power is applied to the EVM.

Input Connections:

1. Prior to connecting the dc input source V_{in} , it is advisable to limit the source current from V_{in} to 10 A maximum. Ensure that V_{in} is initially set to 0 V and connected as shown in Figure 3.
2. Connect a voltmeter V1 at TP7 (V_{in}) and TP8 (GND) to measure the input voltage.
3. Connect a current meter A1 to measure the input current.

Output Connections:

1. Connect Load to J5, and set Load to constant resistance mode to sink 0 Adc before V_{in} is applied.
2. Connect a voltmeter V2 at TP14 (V_{out}) and TP15 (GND) to measure the output voltage.

Other Connections:

Place a fan as shown in Figure 3 and turn on, ensuring that air is flowing across the EVM.

6 Configurations

All jumper selections must be made prior to applying power to the EVM. Users can configure this EVM per the following configurations.

6.1 Switching Frequency Selection

The switching frequency can be set by J1.

Default setting: 300kHz

Table 2. Switching Frequency Selection

Jumper Set to	Resistor (RF) Connections (Ω)	Switching Frequency (kHz)
Top(1-2 pin shorted)	0	250
Second (3-4 pin shorted)	187k	300
Third (5-6 pin shorted)	619k	400
Fourth (7-8 pin shorted)	Open	500
Fifth (9-10 pin shorted)	866k	650
Sixth (11-12 pin shorted)	309k	750
Seventh (13-14 pin shorted)	124k	850
Bottom (15-16 pin shorted)	0	1000

6.2 Soft-Start Selection

The soft-start time can be set by J2.

Default setting: 0.7ms

Table 3. Soft-Start Selection

Jumper Set to	R _{MODE} Connections (Ω)	Soft-Start Time (ms)
Top (1-2 pin shorted)	39.2k	0.7
Second (3-4 pin shorted)	100k	1.4
Third (5-6 pin shorted)	200k	2.8
Bottom (7-8 pin shorted)	475k	5.6

6.3 Mode Selection

The MODE can be set by J6.

Default setting: Auto Skip

Table 4. MODE Selection

Jumper Set to	MODE Selection
Top (1-2 pin shorted)	Auto Skip
Bottom (3-4 pin shorted)	Forced CCM

6.4 Enable Selection

The controller can be enabled and disabled by J3.

Default setting: Jumper shorts on J3 to disable the controller

Table 5. Enable Selection

Jumper Set to	Enable Selection
Jumper shorts on J3	Disable the controller
No Jumper shorts on J3	Enable the controller

7 Test Procedure

7.1 Line/Load Regulation and Efficiency Measurement Procedure

1. Set up EVM as described in [Section 5](#) and [Figure 3](#).
2. Ensure that Load is set to constant resistance mode and to sink 0 Adc.
3. Ensure that all jumper configuration settings per [Section 6](#).
4. Ensure that the jumper provided in the EVM shorts on J3 before Vin is applied.

5. Increase V_{in} from 0 V to 12 V. Using V1 to measure input voltage.
6. Remove the jumper on J3 to enable the controller.
7. Use V2 to measure V_{out} voltage.
8. Vary Load from 0-25 Adc; V_{out} must remain in load regulation.
9. Vary V_{in} from 8 V to 14 V, V_{out} must remain in line regulation.
10. Put the jumper on J3 to disable the controller.
11. Decrease Load to 0 A.
12. Decrease V_{in} to 0 V.

7.2 Control Loop Gain and Phase Measurement Procedure

TPS53219EVM-690 contains a 10- Ω series resistor in the feedback loop for loop response analysis.

1. Set up EVM as described in [Section 5](#) and [Figure 3](#).
2. Connect isolation transformer to test points marked TP9 and TP10.
3. Connect input signal amplitude measurement probe (channel A) to TP9. Connect output signal amplitude measurement probe (channel B) to TP10.
4. Connect ground lead of channel A and channel B to TP11.
5. Inject approximately 40-mV or less signal through the isolation transformer.
6. Sweep the frequency from 100 Hz to 1 MHz with 10 Hz or lower post filter. The control loop gain and phase margin can be measured.
7. Disconnect isolation transformer from bode plot test points before making other measurements. (Signal injection into feedback may interfere with accuracy of other measurements.)

7.3 List of Test Points

Table 6. Functions of Each Test Points

Test Points	Name	Description
TP1	VREG	6.2-V LDO Output
TP2	PGOOD	Power Good
TP3	EN	Enable pin
TP4	DRVH	High-side driver output
TP5	DRVL	Low-side driver output
TP6	MODE	Soft-start and Auto skip/FCCM selection pin
TP7	V_{in}	V_{in}
TP8	GND	GND for V_{in}
TP9	CHA	Input A for loop injection
TP10	CHB	Input B for loop injection
TP11	GND	GND
TP12	GND	GND
TP13	VDD	Controller power supply input
TP14	V_{out}	Output Voltage
TP15	GND	GND for output voltage

7.4 Equipment Shutdown

1. Shut down Load.
2. Shut down V_{in} .
3. Shut down FAN.

8 Performance Data and Typical Characteristic Curves

Figure 4 through Figure 12 present typical performance curves for TPS53219EVM-690.

8.1 Efficiency




Figure 4. Efficiency

8.2 Load Regulation




Figure 5. Load Regulation

8.3 Output Transient




Figure 6. Output Load Transient




Figure 7. Output Load Transient

8.4 Output Ripple




Figure 8. Output Ripple

8.5 Switching Node




Figure 9. Switching Node

8.6 Enable Turnon/Turnoff




Figure 10. Enable Turnon




Figure 11. Enable Turnoff

8.7 Output 1.1-V Prebias Turnon




Figure 12. Output 1.1-V Prebias Turnon

8.8 Bode Plot



Figure 13. Bode Plot at 12 Vin, 1.1 V/25 A

8.9 Thermal Image




Figure 14. Top Board at 12 Vin, 1.1 V/25 A




Figure 15. Bottom Board at 12 Vin, 1.1 V/25 A

9 EVM Assembly Drawing and PCB Layout

Figure 16 through Figure 23 show the design of the TPS53219EVM-690 printed-circuit board. The EVM has been designed using six Layers, 2-oz copper circuit board.




Figure 16. TPS53219EVM-690 Top Layer Assembly Drawing, Top View




Figure 17. TPS53219EVM-690 Bottom Assembly Drawing, Bottom View




Figure 18. TPS53219EVM-690 Top Copper, Top View




Figure 19. TPS53219EVM-690 Layer-2 Copper, Top View




Figure 20. TPS53219EVM-690 Layer-3 Copper, Top View




Figure 21. TPS53219EVM-690 Layer-4 Copper, Top View




Figure 22. TPS53219EVM-690 Layer-5 Copper, Top View




Figure 23. TPS53219EVM-690 Bottom Layer Copper, Top View

10 Bill of Materials

Table 7. The EVM Bill of Materials According to Schematic Shown in Figure 1

Qty	RefDes	Description	MFR	Part Number
1	C1	Capacitor, Ceramic, 4.7 μ F, 16V, X5R, 20%, 0805	STD	STD
5	C12–C16	Capacitor, Ceramic, 100 μ F, 6.3V, X5R, 20%, 1210	Murata	GRM32ER60J107ME20L
1	C19	Capacitor, Ceramic, 4700 pF, 50V, X7R, 20%, 0603	STD	STD
2	C2, C20	Capacitor, Ceramic, 1000 pF, 25V, X7R, 10%, 0603	STD	STD
2	C3, C10	Capacitor, Ceramic, 0.1 μ F, 50V, X7R, 10%, 0603	STD	STD
1	C5	Capacitor, Ceramic, 0.027 μ F, 50V, X7R, 10%, 0603	STD	STD
1	C4	Capacitor, Ceramic, 1 μ F, 16V, X7R, 10%, 0603	STD	STD
4	C6–C9	Capacitor, Ceramic, 22 μ F, 16V, X5R, 20%, 1206	Murata	GRM31CR61C226ME15L
1	L1	Inductor, SMT, 0.44 μ H, 30A, 0.0032ohms, 0.530"x0.510"	Pulse or E&E Magnetic	PA0513-441NLT or 831-02990F
1	Q1	MOSFET, Dual N-chan, Power Block, 25V, 40A, QFN-8 Power	TI	CSD86350Q5D
3	R1, R3, R22	Resistor, Chip, 100k, 1/16W, 1%, 0603	STD	STD
1	R15	Resistor, Chip, 187k, 1/16W, 1%, 0603	STD	STD
1	R16	Resistor, Chip, 619k, 1/16W, 1%, 0603	STD	STD
1	R18	Resistor, Chip, 866k, 1/16W, 1%, 0603	STD	STD
1	R19	Resistor, Chip, 309k, 1/16W, 1%, 0603	STD	STD
2	R2, R23	Resistor, Chip, 200k, 1/16W, 1%, 0603	STD	STD
1	R20	Resistor, Chip, 124k, 1/16W, 1%, 0603	STD	STD
1	R21	Resistor, Chip, 39.2k, 1/16W, 1%, 0603	STD	STD
1	R24	Resistor, Chip, 475k, 1/16W, 1%, 0603	STD	STD
1	R26	Resistor, Chip, 1, 1/10W, 5%, 0805	STD	STD
1	R4	Resistor, Chip, 1.00k, 1/16W, 1%, 0603	STD	STD
1	R5	Resistor, Chip, 35.7k, 1/16W, 1%, 0603	STD	STD
6	R6, R11–R13, R25, R27	Resistor, Chip, 0, 1/16W, 5%, 0603	STD	STD
1	R10	Resistor, Chip, 5.11, 1/16W, 1%, 0603	STD	STD
2	R7, R14	Resistor, Chip, 10.0k, 1/16W, 1%, 0603	STD	STD
1	R8	Resistor, Chip, 8.25k, 1/16W, 1%, 0603	STD	STD
1	R9	Resistor, Chip, 10, 1/16W, 1%, 0603	STD	STD
1	U1	IC, Single Synchronous Step-Down Controller, QFN-16	TI	TPS53219RGT

Evaluation Board/Kit Important Notice

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation board/kit is intended for use for **ENGINEERING DEVELOPMENT, DEMONSTRATION, OR EVALUATION PURPOSES ONLY** and is not considered by TI to be a finished end-product fit for general consumer use. Persons handling the product(s) must have electronics training and observe good engineering practice standards. As such, the goods being provided are not intended to be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety and environmental measures typically found in end products that incorporate such semiconductor components or circuit boards. This evaluation board/kit does not fall within the scope of the European Union directives regarding electromagnetic compatibility, restricted substances (RoHS), recycling (WEEE), FCC, CE or UL, and therefore may not meet the technical requirements of these directives or other related directives.

Should this evaluation board/kit not meet the specifications indicated in the User's Guide, the board/kit may be returned within 30 days from the date of delivery for a full refund. **THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.**

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive.**

TI assumes **no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.**

Please read the User's Guide and, specifically, the Warnings and Restrictions notice in the User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For additional information on TI's environmental and/or safety programs, please contact the TI application engineer or visit www.ti.com/esh.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

FCC Warning

This evaluation board/kit is intended for use for **ENGINEERING DEVELOPMENT, DEMONSTRATION, OR EVALUATION PURPOSES ONLY** and is not considered by TI to be a finished end-product fit for general consumer use. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

EVM Warnings and Restrictions

It is important to operate this EVM within the input voltage range of 8 V to 14 V and the output voltage range of 0.3 V to 1.5 V .

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 70°C. The EVM is designed to operate properly with certain components above 70°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2011, Texas Instruments Incorporated

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
RF/IF and ZigBee® Solutions	www.ti.com/lprf

Applications

Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Transportation and Automotive	www.ti.com/automotive
Video and Imaging	www.ti.com/video
Wireless	www.ti.com/wireless-apps

TI E2E Community Home Page

e2e.ti.com

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265
Copyright © 2011, Texas Instruments Incorporated